

WD TV™ HD Media Player

Technical Support Services

support.wdc.com
www.westerndigital.com
800.ASK.4WDC North America
800.832.4778 Spanish
+800.6008.8008 Asia Pacific
00800.27549338 Europe (toll free where available)
+31.880062100 Europe/Middle East/Africa

Western Digital
20511 Lake Forest Drive
Lake Forest, California 92630
U.S.A.

Western Digital, WD, the WD logo, and My Book are registered trademarks in the U.S. and other countries; and
WD TV HD Media Player and My Passport are trademarks of Western Digital Technologies, Inc. Other marks may be mentioned herein that belong to other companies. Specifications subject to change without notice.

© 2008 Western Digital Technologies, Inc. All rights reserved.
4079-705022-802 Dec 2008



1

Diagram showing the WD TV HD Media Player connected to a laptop via a USB cable. Icons for music, video, and photos are shown above the laptop screen.

2

Diagram showing the power supply unit with various international power plugs labeled: US/JA/TW, EU/KO, UK, CH, AU/NZ. The power supply is shown plugged into a wall outlet.

3

Diagram showing the WD TV HD Media Player connected to a television. Two options are shown: Standard Definition (SD) using composite video cables and High Definition (HD) using an HDMI cable. The HDMI cable is labeled "HDMI (sold separately)".

4

Diagram showing the WD TV HD Media Player connected to a My Passport™ portable drive and a My Book® external drive via USB 2.0 cables. A temperature warning icon is shown with the text: 5°C - 35°C / 41°F - 95°F. A note at the bottom states: "My Passport and stand, My Book, and USB cables sold separately".

5

Diagram showing the WD TV HD Media Player connected to a television. The TV screen displays a "Videos" menu. A remote control is shown in front of the TV.

6

Diagram showing a laptop with a disc in its drive. A list of requirements is provided:

- ArcSoft Media Converter Software
- User Manual
- Sample HD Media

Minimum Installation Requirements

- Standard or HD television with HDMI or composite video input.
- External USB storage device.

Requisiti minimi di installazione

- Televisore standard o HD con ingresso video HDMI o composito.
- Dispositivo di archiviazione con interfaccia USB.

Requisitos mínimos de instalación

- Televisión estándar o HD con HDMI o entrada de video compuesto.
- Dispositivo de almacenamiento USB externo.

Requisitos Mínimos de Instalação

- Televisão HD ou padrão com HDMI ou entrada para vídeo composto.
- Dispositivo de armazenamento USB externo.

Minimale installatievereisten

- Standaard- of HD-televisie met HDMI- of composietvideo-ingang.
- Extern USB-opslagapparaat.

Минимальные требования для установки

- Стандартный или высокой четкости телевизор с HDMI или композитным видеовходом.
- Внешнее устройство хранения USB.

Mindestanforderungen zur Installation

- Standard- oder HD-Fernsehgerät mit HDMI- oder Composite Video-Eingang.
- Externes USB-Speichergerät.

Configuration système requise

- Téléviseur standard ou HD avec entrée HDMI ou vidéo composite.
- Appareil de stockage externe USB.

Minimalne wymagania instalacyjne

- Odbiornik telewizyjny standardowy lub HD z wejściem sygnału HDMI lub kompozytowego wizji (Composite).
- Zewnętrzne urządzenie magazynujące USB.

Minimum installationskrav

- Standard eller HD TV med HDMI eller komposit videooutput.
- Ekstern USB-lagringsenhet.

الحد الأدنى من متطلبات التثبيت

- تلفزيون قياسي أو عالي الدقة مع مدخل فيديو HDMI أو فيديو مركب.
- جهاز تخزين USB.

Minimum Kurulum Gereksinimleri

- HDMI veya bileşik video girişi içeren Standart ya da HD televizyon.
- Harici USB depolama aygıtı.

Minimální požadavky pro instalaci

- Běžný televizor nebo televizor s vysokým rozlišením HD s kompozitním nebo HDMI video vstupem.
- Externí USB paměťové úložné zařízení.

Μinimální požadavky pro instalaci

- Τυπική τηλεόραση ή τηλεόραση HD με HDMI ή σύνθετη είσοδο βίντεο.
- Εξωτερική συσκευή αποθήκευσης USB.

Asennuksen vähimmäisvaatimukset

- Tavallinen tai HD-televisio, jossa on HDMI- tai kompositivideoisäätintulo.
- Ulkoinen USB-muistilaitte.

Lägsta krav för installation

- Standard- eller HD-TV med HDMI- eller kompositvideoingång.
- Extern USB-lagringsenhet.

Minimálne požiadavky na inštaláciu

- Štandardný televízor alebo televízor s rozlíšením HD so vstupom HDMI alebo kompozitným vstupom pre video.
- Externé pamäťové zariadenie pre USB.

最小インストール要件

- HDMI またはコンポジットビデオ信号入力に装備された標準 TV または HD TV.
- 外付け USB ストレージ デバイス。

최소 설치 요구 사항

- HDMI 또는 합성 비디오 입력이 있는 일반 또는 HD TV.
- 외부 USB 스토리지 장치.

最低安裝需求

- 具有 HDMI 或複合視頻輸出的標準或 HD 電視。
- 外接式 USB 儲存裝置。

最低安裝要求

- 帶 HDMI 或複合視頻輸入的標準或 HD 電視。
- 外部 USB 存儲設備。